

Steps to Trouble Shooting your Chrome Book


My Chrome book is not connecting to the Internet.

Here is a Possible solution:

Your computer has lost its connection.

Solution:

Move your mouse to the bottom right corner of your screen.



Click on bottom right and go to “not connected” circle.

Click on it and select your home wifi